



INDENT LIGHTLY E-H, I-L, F-J, G-K, A-F, D-G, J-M, K-P

ON TOP SIDE OF METAL.

INDENT LIGHTLY B-F, C-G, J-N, K-O ON BOTTOM SIDE.

~~BEND~~ E-H AND I-L TO VERTICAL POSITION.

SLIGHTLY BEND A-F, D-G, J-M, K-P AND AT SAME

TIME SLIGHTLY BEND B-F, C-G, J-N, K-O.

BEND EARLY TOWARDS ENDS AND THEN POUND ALL

EDGES WITH HAMMER.

65-1950
30

LETTER-KENNEY ARSENAL
(ARMY SHOTGUNS)

